

- 1 Conduct a training session for CyberPoint users. Let them insert their key in a CyberPoint.
- 2 Insert the key straight into the lock, not at an angle.
- 3 Do not twist or turn the key while the key is inside the CyberPoint.
- 4 Wait until the key either beeps three times or flashes a steady green light with quick red flashes. This means that the transfer of information is completed between the CyberPoint and key.
- 5 For good electrical contact, it may occasionally be necessary to clean contaminants from the tip of the key and the face of the CyberPoint. Videx provides a stainless steel bristle brush that works well for doing this; please contact Videx for details.



1105 N.E. Circle Blvd., Corvallis, OR 97330

541-758-0521 • Fax 541-752-5285 • [www.videx.com](http://www.videx.com) • [sales@videx.com](mailto:sales@videx.com) • [support@videx.com](mailto:support@videx.com)

Videx and CyberKey are registered trademarks of Videx, Inc. GCO2517